



The tree strap installation instruction




Attention


- 1: The standard length of the tree strap is 1M, suitable for the tree with a max diameter of 300MM.
- 2: Please change immediately when finding any damage or fracture during installation.
- 3: Please change immediately when any product without fastening function is founded during installation.
- 4: It can't be directly installed on the combustibles surface.
- 5: The length of the tree strap can be customized according to the object's diameter.




Identify the installation holes corresponding to the hoop bracket and the lamp base, fasten them with fixing screws.



Ensure the tight connection between the bracket and the lamp base, avoid the damage caused by loosening and falling off.



Make the bracket perpendicular to the object, force the bracket and the object to be connected tightly, and then tie the tree strap and the clasp



**The same products
As is shown**